















Shock Absorber Kit - Nivomat to Standard

Model	Year	Art No	
740,940 All Sedan models Nivomat to standard kit - HD spring	All	72439500C	
745, 945 All Wagon models Nivomat to standard kit - HD spring	All	72439501C	
855,V70 W/o AWD Nivomat to standard kit	-2000	72431870C	
855,V70 W/o AWD Nivomat to standard kit - HD spring	-2000	72431871C	
850,S70 W/o AWD Nivomat to standard kit	-2000	72431872C	
850,S70 W/o AWD Nivomat to standard kit - HD spring	-2000	72431873C	
S80 2WD Nivomat to standard kit	1999-06	72430407C	
S60 2WD Nivomat to standard kit	2001-09	72430408C	

Shock Absorber Kit - Nivomat to Standard				
Model		Year	Art No	
V70II	2WD Nivomat to standard kit	2000-07	72430406C	
V70II	2WD Nivomat to standard kit - HD spring	2000-07	72430406CHD	
V70III	Nivomat to standard kit	2008-	72434221C	
V70III	Nivomat to standard kit - HD spring	2008-	72434221CHD	
XC70	Nivomat to standard kit	2000-07	72430056C	
XC70	Nivomat to standard kit - HD spring	2000-07	72430057C	
XC90	Nivomat to standard kit	2003-14	72439513C	