













# Content

Audi	2-3
Ford	4
Saab	5
Volkswagen	6
Volvo	7-8

<b>Remote Control Cover</b>					
<b>Model</b>	<b>Type</b>	<b>Year</b>	<b>Oe Ref</b>	<b>Art No</b>	
A8, A6, A6L A4, A3 A2, TT	Remote control cover. Uncut flip key w/o software. 3 buttons including trunk switch.			<b>83020005</b>	
A8 Quattro Q7	Remote control cover. Uncut flip key w/o software. 3 buttons including trunk switch + 1 alarm switch. Small battery. Length 64mm Width 35mm Height 18mm			<b>83020004</b>	
A8 Quattro Q7	Remote control cover. Uncut flip key w/o software. 3 buttons including trunk switch + 1 alarm switch. Large battery. Length 64mm Width 35mm Height 18mm			<b>83021004</b>	
A4, S4 A3, S3	Remote control cover. Uncut flip key w/o software. 2 buttons + 1 alarm switch. Small battery cage. Length 64mm Width 35mm Height 18mm		4DO 837 231	<b>83020001</b>	
A4, S4 A3, S3	Remote control cover. Uncut flip key w/o software. 2 buttons + 1 alarm switch. Large battery cage. Length 64mm Width 35mm Height 18mm		4DO 837 231	<b>83021001</b>	





<b>Remote Control Cover</b>					
<b>Model</b>	<b>Type</b>	<b>Year</b>	<b>Oe Ref</b>	<b>Art No</b>	
A4, S4 A3, S3	Remote control cover. Uncut flip key w/o software. 2 buttons. Small battery cage. Length 64mm Width 35mm Height 18mm		4DO 837 231	<b>83020002</b>	
A4, S4 A3, S3	Remote control cover. Uncut flip key w/o software. 2 buttons. Large battery cage. Length 64mm Width 35mm Height 18mm		4DO 837 231	<b>83021002</b>	
A4, A3 A2	Remote control cover. Uncut flip key w/o software. 3 buttons including trunk switch. Small battery cage. Length 64mm Width 35mm Height 18mm			<b>83020003</b>	
A4, A3 A2	Remote control cover. Uncut flip key w/o software. 3 buttons including trunk switch. Large battery cage. Length 64mm Width 35mm Height 18mm			<b>83021003</b>	

Any references to part numbers, vehicle models and manufactures are done only for informational purposes. It is not intended to imply affiliation with or approval by the vehicle manufacturer.

Remote Control Cover					
Model	Type	Year	Oe Ref	Art No	
C Max Fiesta Focus Ka	Remote control cover. Flip key w/o software. 3 buttons including trunk switch. Length 70mm Width 36mm Height 16mm			83130001	
Fiesta Focus Mondeo	Remote control cover. Flip key w/o software. 3 buttons including trunk switch. Length 70mm Width 36mm Height 16mm			83130002	

<b>Remote Control Cover</b>					
<b>Model</b>	<b>Type</b>	<b>Year</b>	<b>Oe Ref</b>	<b>Art No</b>	
9-3	Remote control cover. Without key or software.	2003-	12783781 (12783780) (12783779) (12801309) (12758289) (12764369) (12767979) (12801310) (12758288) (12764370) (12767978) (12801311) (12758287) (12764371) (12767977)	<b>83343781</b>	
	Blank key fo remote control cover 83343781.		12787976	<b>83343781-1</b>	

Any references to part numbers, vehicle models and manufactures are done only for informational purposes. It is not intended to imply affiliation with or approval by the vehicle manufacturer.

<b>Remote Control Cover</b>					
<b>Model</b>	<b>Type</b>	<b>Year</b>	<b>Oe Ref</b>	<b>Art No</b>	
Beetle Golf GTI Jetta Passat Rabbit Touareg	Remote control cover. Uncut flip key w/o software. 2 buttons. Length 65mm Width 35mm Height 18mm	1998- 2006- 2007- 1998- 1998- 2006- 2007-	1J0 959 753 CT 1K0 959 753 LD	<b>83420002</b>	
Beetle Golf GTI Jetta Passat Rabbit Touareg	Remote control cover. Uncut flip key w/o software. 2 buttons + 1 alarm switch. Length 65mm Width 35mm Height 18mm	1998- 2006- 2007- 1998- 1998- 2006- 2007-	1J0 959 753 F	<b>83420004</b>	
Beetle Golf GTI Jetta Jetta Passat Scirocco	(GL-GLS-VR6-GTI)  (GL - GLX)  Remote control cover. Uncut flip key w/o software. 3 buttons including trunk switch + 1 alarm switch. Length 65mm Width 35mm Height 18mm	2002- 2002- 2000- 1998- 2002- 2001-	1J0 959 753 AM 1K0 959 753 P 1J0 959 753 T 1J0 959 753 DC	<b>83420001</b>	
Beetle Golf GTI Jetta Jetta Passat Scirocco	(GL - GLS - VR6 - GTI)  (GL - GLX)  Remote control cover. Uncut flip key w/o software. 3 buttons including trunk switch. Length 65mm Width 35mm Height 18mm	2002- 2002- 2000- 1998- 2002- 2001-	1J0 959 753 DA 1J0 959 753 AH 1J0 959 753 DJ	<b>83420003</b>	

<b>Remote Control Cover and Insert</b>					
<b>Model</b>	<b>Type</b>	<b>Year</b>	<b>Oe Ref</b>	<b>Art No</b>	
S/V40	Remote control cover. 2 holes.	2000-04	30857610 (30857616)	<b>83437610</b>	
S/V40	Remote control cover insert.	2000-04	30857610 (30857616)	<b>83430610</b>	
S/V70	Remote control cover. Three holes, included trunk switch.	-2000	9166199 (9184784)	<b>83436199</b>	
S/V70	Remote control cover insert. Included trunk switch.	-2000	9166199 (9184784)	<b>83430199</b>	
S/V70	Remote control cover. Four holes, included trunk and alarm switch.	-2000	9166200	<b>83436200</b>	
S/V70	Remote control cover insert. Included trunk and alarm switch.	-2000	9166200	<b>83430200</b>	


Any references to part numbers, vehicle models and manufactures are done only for informational purposes. It is not intended to imply affiliation with or approval by the vehicle manufacturer.

<b>Remote Control Cover and Insert</b>					
<b>Model</b>	<b>Type</b>	<b>Year</b>	<b>Oe Ref</b>	<b>Art No</b>	
S60/80 V70N	Remote control cover Four holes, included trunk switch	1999-03 2000-04	9452457 (9459365) (9459366) (9459371) (9459367) (9452455) (8685149) (9459369) (9459373) (9459372) (8685151)	<b>83432457</b>	
S60/80 V70N	Remote control cover insert	1999-03 2000-04	9452457	<b>83430457</b>	
S60 S80 V70 XC70	Remote control cover Ch -147 Ch -161195 FC1 Ch -45075, FC2 Ch -47578 Ch -3972 Four holes, included trunk and alarm switch	2001-03 1999-03 2000-03 2001-03	9459368 (9452456-8) (8685150)	<b>83439368</b>	
S60 S80 V70 XC70	Remote control cover insert Ch -147 Ch -161195 FC1 Ch -45075, FC2 Ch -47578 Ch -3972 Four buttons, included trunk and alarm switch	2001-03 1999-03 2000-03 2001-03		<b>83430368</b>	
S60 S80 V70 XC70 XC90	Remote control cover Four buttons, included trunk and alarm switch	2004-09 2004-06 2004-07 2004-07 2003-	8688800 (31253452) (8688799) (8688798) (8626557)	<b>83438800</b>	



**Replacement guide for 83438800 S60I, S80I, V70II, XC70II & XC90**

1) Open the old remote control cover.  
Carefully saw the middle upper part  
using a hacksaw where shown  
in the picture (it is glued together)



2) Cut out the small chip from inside the lid.  
Use caution, chip is very fragile.  
Put chip into the new remote control cover,  
close it and check that it works properly



3) See to that the key feather is properly  
mounted for opening of the manual key.  
Glue together chip and lid



4) You are now ready to start using  
your new Proparts remote control cover!

